




***DD-PAD***  
**Assembly Manual**  
取扱説明書




G6047096R0-00

## PARTS LIST


① BASE (6pcs)  
機座




④ Sensor (5pcs)  
感測片




⑥ Rubber pice (5pcs)  
矽膠片




② Panel Board  
控制板




③ Main Board  
主機板




⑤ Stay (9pcs)  
連接支座



⑦ Cable Black/Yellow (8pcs)  
黃黑線



⑧ Cable Black/Red (8pcs)  
紅黑線



⑨ [CUP 3x6] (18pcs)



⑩ [BIND 3x4] (5pcs)



⑪ [NUT M3x2t] (5pcs)



⑫ [Rubber foot] (48pcs)



⑬ Screw bolt (5pcs)



⑭ [LED SET] (5pcs)




⑮ [LED NUT] (5pcs)




Parts

## TOOL LIST




Screwdriver +



黄色テープ  
TAPE width10  
Use Fix Cable


Tools

# 1 ASSY-Control Board




**!** 需使用沒有貼砂膠片的機座  
Rubber Piceが貼ってないBASEで使用ください、

**1-1** L-hole 4 point  
L-孔 4點




**⑬** Screw bolt (4pcs)





**①** BASE  
機座

**⑫** Rubber foot (6pcs)  
腳墊 (6pcs)




**⑪** NUT M3x2t (4pcs)




**Rubber foot to paste on the Base**  
將腳墊貼在機座上  
Rubber FootをBaseの上に貼付

1-2




1-3





1-2 ~ 1-3

## 2 ASSY-PAD x 5set





### 2-1



Release paper to remove  
去除離型紙  
剝離紙を剝離




Sensor to paste on the Base  
將感測片貼在機座上  
SensorをBaseの上に貼付

### 2-2




2-1 ~ 2-2

2-3




2-4

⑭ LED SET





Into the hole  
穿過孔  
穴に入れ



2-5


⑮ [LED NUT]

Screw LED NUT




2-3 ~ 2-5

2-6




2-7




2-6 ~ 2-7



2-8




2-9




2-8 ~ 2-9

### 3 ASSY TOP DD-PAD

3-1





### 3-2




**Using in Sensor**  
用於感測片  
Sensorで使用

**Sensor & LED**  
**Correspondence position**  
感測片與LED需相對應連接  
SensorとLED  
同じな順番で付ける






Assembly Example 1





Assembly Example 2




## CONNECTIONS


The diagram illustrates the connection points for the device. A smartphone is connected to the AUX-IN port. A USB charger is connected to the MINI USB port. A phone is connected to the PHONE OUT port. An AC adaptor is connected to the power input. The device is shown with its internal components and ports labeled JK1 and JK2.

**ADVICE POWER SUPPLY :**  
AC ADAPTOR (8V ~ 15V)   
or USB POWER (4.5V ~ 5.5V)

AC ADAPTOR (8V ~ 15V)   
or USB POWER (4.5V ~ 5.5V)



BLE



---

## ■ CONTACT

MAKER HART INDUSTRY CORP.

2F., NO.3, LN. 263, CHONGYANG RD., NANGANG DIST., TAIPEI CITY 11573, TAIWAN (R.O.C.)

Email : [info@makerhart.com](mailto:info@makerhart.com)

<http://www.makerhart.com>

<https://www.facebook.com/Makerhart2015/>

